



HIGH PERFORMANCE STROLLERS

Glider Board Instructions

Box Includes:

1 Glider Board



Glider Board



WARNING: Always secure seat recline strap to recline clamp before using the Glider Board.



1 Insert wheel axle into the hole on the underside of the Glider Board. The wheel is secure when you hear it click. Repeat on other side.



2 Slide ratchet straps between the lower support bar and the brake rods.



3 Place attachment brackets onto lower support bar.



4 Press ratchet lock tab and slide ratchet strap through opening.



5 Push ratchet strap through until snug. Repeat on other side.


To Adjust Glider Board Angle:

1 Push the safety cover away from the tabs.

2a *To Raise:* Squeeze tabs on right and left side of Glider Board and pull up.

2b *To Lower:* Squeeze tabs on right and left side of Glider Board and push down.

3 Pull the safety cover back over the tabs.



NOTE: GLIDER BOARD MUST BE PARALLEL TO THE GROUND BEFORE USE. Depending on your stroller model, you may need to adjust the angle.

WARNING: Always ensure the safety covers are covering the adjustment tabs prior to use.



HIGH PERFORMANCE STROLLERS

Glider Board Instructions (continued)

To Adjust Glider Board Length:

- 1 Pull handle on the rear-underside of Glider Board.




Pull out to extend.



Push in to shorten.

Storage:

- 1 Raise Glider Board and unhook storage straps from underside.
- 2 Hook storage straps around rear crossbar of stroller frame.



NOTE: When stored, make sure the rear of the Glider Board is not interfering with the back of the stroller seat. Adjust Glider Board length for storage if necessary.

NOTE: The stroller may be folded with the Glider Board in the storage position. The Glider Board wheels must be removed prior to folding the stroller.

WARNING: Always make sure storage straps are fastened to the underside of the Glider Board before use.

To Remove Glider Board:

- 1 Press ratchet lock tab and pull ratchet strap out. Unclip attachment brackets.



To Remove Wheels:

- 1 Press wheel release button and gently pull on wheel to remove.



WARNING: Always make sure the ratchet straps are securely tightened before use.
WARNING: Total weight load recommended for Glider Board is 45 lbs.

The sample product shown in this manual may differ slightly from your production quality Glider Board. However, this will not affect the assembly or functionality of your Baby Jogger product.